

Sony Simple IP Control Protocol for BRAVIA

Version 0.6

Copyright (C) 2013-2014 Sony Corporation
All rights reserved.

1. Overview

BRAVIA 2014 models provide both high level and low-level IP control functions. The former one is called WebAPI that is designed for web developers, and the latter is designed for those who are familiar with CIS and/or A/V control systems.

- High Level Protocol
 - Layer: HTTP
 - Format: JSON-RPC
- Low Level Protocol
 - Layer: TCP
 - Format: Fixed-sized Byte Stream

Table of Contents

1. Overview
2. Connection
3. Data Format
3.1 Header
3.2 Type
3.3 Function
4. Command Definition
4.1 Common Parameter Definition
4.2 All Command Definitions
4.3 IR Commands

Low Level Protocol is designed as a protocol bridge to High Level Protocol. All commands defined in Low Level Protocol are available in High Level Protocol.

In order to enable this protocol, either one of the following settings needs to be enabled.

- Normal Mode
 - Network > Home Network Setup > IP Control > Simple IP Control
- Hotel/Pro Mode
 - Hotel/Pro Mode > IP Control > Simple IP Control

2. Connection

The server running on BRAVIA listens on TCP port 20060. TCP connections are kept among requests but they are disconnected by server if no command is sent from client in 30 seconds.

3. Data Format

The protocol has 24 bytes fixed-size data format on TCP. Table 1 shows the data format.

Table 1 Data Format

Byte Position	Name	Length	Value
0	Header	2 bytes	0x2A [*]: (fixed value)
1			0x53 [S]: (fixed value)
2	Type	1 byte	0x43 [C]: Control 0x45 [E]: Enquiry 0x41 [A]: Answer 0x4E [N]: Notify
3	Function	4 bytes	0xXX
4			0xXX
5			0xXX
6			0xXX
7	Parameter	16 bytes	0xXX
8			0xXX
9			0xXX
10			0xXX
11			0xXX
12			0xXX
13			0xXX
14			0xXX

15			0xXX
16			0xXX
17			0xXX
18			0xXX
19			0xXX
20			0xXX
21			0xXX
22			0xXX
23	Footer	1 byte	0x0A [LF]: (fixed value)

3.1 Header

Each message always has the fixed header (0x2A 0x53), which identifies the beginning of message.

3.2 Type

There are 4 message types are defined as Table 2.

Table 2 Message Types

Type	Value	Direction	Detail
Control	0x43 [C]	Controller to TV	Used to control or change the value on TV Answer message is used for reply
Enquiry	0x45 [E]	Controller to TV	Used to retrieve values or status from TV Answer message is used for reply
Answer	0x41 [A]	TV to Controller	Used to send a reply back to controller
Notify	0x4E [N]	TV to Controller	Used to send an event to controller from TV

3.3 Function

Each function is identified by four ASCII characters represented in Four-CC format.

- <http://en.wikipedia.org/wiki/FourCC>

The detail command definition is described in section 4.

4. Command Definition

4.1 Common Parameter Definition

Table 3 shows the common parameter definition.

Table 3 Common Parameters

Type	Parameter (0 - 15)	Description
C	# # # # # # # # # # # # # # # #	Used for control with no parameter e.g.) Toggle functions
E	# # # # # # # # # # # # # # # #	Used for inquiry with no parameter
A	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Answer with success e.g.) Control result
A	F F F F F F F F F F F F F F F F	Answer with error e.g.) Invalid parameter

4.2 All Command Definitions

Table 4 Command List

Function Name	Type	FourCC	Parameter (0 - 15)	Description
setIrccCode	C	I R C	C X	Send IR like code. See Table 5.
	A		0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Success
	A		F F F F F F F F F F F F F F F F	Error
setPowerStatus	C	P O W R	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Standby (Off)

	C					0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	Active (On)
	A					0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	Success
	A					F	F	F	F	F	F	F	F	F	F	F	F	F	F	F	F	Error
getPowerStatus	E	P	O	W	R	#	#	#	#	#	#	#	#	#	#	#	#	#	#	#	#	
	A					0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	Standby (Off)
	A					0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	Active (On)
	A					F	F	F	F	F	F	F	F	F	F	F	F	F	F	F	F	Error
setAudioVolume	C	V	O	L	U	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	Set volume value in decimal digit pad on the left with "0" e.g.) 0000000000000029
	A					0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	Success
	A					F	F	F	F	F	F	F	F	F	F	F	F	F	F	F	F	Error
getAudioVolume	E	V	O	L	U	#	#	#	#	#	#	#	#	#	#	#	#	#	#	#	#	Get audio volume value
	A					X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	Success with volume value
	A					F	F	F	F	F	F	F	F	F	F	F	F	F	F	F	F	Error
setAudioMute	C	A	M	U	T	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	Unmute
	C					0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	Mute
	A					0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	Success
	A					F	F	F	F	F	F	F	F	F	F	F	F	F	F	F	F	Error
getAudioMute	E	A	M	U	T	#	#	#	#	#	#	#	#	#	#	#	#	#	#	#	#	Get audio mute status
	A					0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	Not Muted
	A					0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	Muted
	A					F	F	F	F	F	F	F	F	F	F	F	F	F	F	F	F	Error
setChannel	C	C	H	N	N	X	X	X	X	X	X	X	X	X	.	X	X	X	X	X	X	Change channel with preset number - 00000050.1000000 means channel 50.1 - 00000006.0000000 means channel 6
	A					N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	No such channel
	A					0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	Success
	A					F	F	F	F	F	F	F	F	F	F	F	F	F	F	F	F	Error
getChannel	E	C	H	N	N	#	#	#	#	#	#	#	#	#	#	#	#	#	#	#	#	Get current preset channel number
	A					X	X	X	X	X	X	X	X	X	.	X	X	X	X	X	X	Preset channel number
	A					F	F	F	F	F	F	F	F	F	F	F	F	F	F	F	F	Error
setTripletChannel	C	T	C	H	N	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	Change channel with triplet in hexadecimal e.g.) 7FE07FE00400 means 32736.32736.1024
	A					N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	No such channel
	A					0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	Success
	A					F	F	F	F	F	F	F	F	F	F	F	F	F	F	F	F	Error
getTripletChannel	E	T	C	H	N	#	#	#	#	#	#	#	#	#	#	#	#	#	#	#	#	Get current triplet channel number
	A					X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	Triplet channel number
	A					F	F	F	F	F	F	F	F	F	F	F	F	F	F	F	F	Error
																						Change TV input source pad on the right with "#" e.g.) dvbt##### - dvbt

4.3 IR Commands

IR like control commands are supported on setIrccCode defined in Table 4. The supported codes and their parameters are defined in Table 5.

Table 5 IR Command Parameters

IR Function	Parameter (0-15)
Power Off	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
Input	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 1
GGuide	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 2
EPG	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 3
Favorites	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 4
Display	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 5
Home	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 6
Options	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 7
Return	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 8
Up	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 9
Down	0 0 0 0 0 0 0 0 0 0 0 0 0 0 1 0
Right	0 0 0 0 0 0 0 0 0 0 0 0 0 0 1 1
Left	0 0 0 0 0 0 0 0 0 0 0 0 0 0 1 2
Confirm	0 0 0 0 0 0 0 0 0 0 0 0 0 0 1 3
Red	0 0 0 0 0 0 0 0 0 0 0 0 0 0 1 4
Green	0 0 0 0 0 0 0 0 0 0 0 0 0 0 1 5
Yellow	0 0 0 0 0 0 0 0 0 0 0 0 0 0 1 6
Blue	0 0 0 0 0 0 0 0 0 0 0 0 0 0 1 7
Num1	0 0 0 0 0 0 0 0 0 0 0 0 0 0 1 8
Num2	0 0 0 0 0 0 0 0 0 0 0 0 0 0 1 9
Num3	0 0 0 0 0 0 0 0 0 0 0 0 0 0 2 0
Num4	0 0 0 0 0 0 0 0 0 0 0 0 0 0 2 1
Num5	0 0 0 0 0 0 0 0 0 0 0 0 0 0 2 2
Num6	0 0 0 0 0 0 0 0 0 0 0 0 0 0 2 3
Num7	0 0 0 0 0 0 0 0 0 0 0 0 0 0 2 4
Num8	0 0 0 0 0 0 0 0 0 0 0 0 0 0 2 5
Num9	0 0 0 0 0 0 0 0 0 0 0 0 0 0 2 6
Num0	0 0 0 0 0 0 0 0 0 0 0 0 0 0 2 7
Num11	0 0 0 0 0 0 0 0 0 0 0 0 0 0 2 8
Num12	0 0 0 0 0 0 0 0 0 0 0 0 0 0 2 9
Volume Up	0 0 0 0 0 0 0 0 0 0 0 0 0 0 3 0
Volume Down	0 0 0 0 0 0 0 0 0 0 0 0 0 0 3 1
Mute	0 0 0 0 0 0 0 0 0 0 0 0 0 0 3 2
Channel Up	0 0 0 0 0 0 0 0 0 0 0 0 0 0 3 3
Channel Down	0 0 0 0 0 0 0 0 0 0 0 0 0 0 3 4
Subtitle	0 0 0 0 0 0 0 0 0 0 0 0 0 0 3 5
Closed Caption	0 0 0 0 0 0 0 0 0 0 0 0 0 0 3 6
Enter	0 0 0 0 0 0 0 0 0 0 0 0 0 0 3 7
DOT	0 0 0 0 0 0 0 0 0 0 0 0 0 0 3 8
Analog	0 0 0 0 0 0 0 0 0 0 0 0 0 0 3 9
Teletext	0 0 0 0 0 0 0 0 0 0 0 0 0 0 4 0
Exit	0 0 0 0 0 0 0 0 0 0 0 0 0 0 4 1
Analog2	0 0 0 0 0 0 0 0 0 0 0 0 0 0 4 2
*AD	0 0 0 0 0 0 0 0 0 0 0 0 0 0 4 3
Digital	0 0 0 0 0 0 0 0 0 0 0 0 0 0 4 4
Analog?	0 0 0 0 0 0 0 0 0 0 0 0 0 0 4 5
BS	0 0 0 0 0 0 0 0 0 0 0 0 0 0 4 6
CS	0 0 0 0 0 0 0 0 0 0 0 0 0 0 4 7
BS/CS	0 0 0 0 0 0 0 0 0 0 0 0 0 0 4 8
Ddata	0 0 0 0 0 0 0 0 0 0 0 0 0 0 4 9

